### More HP resources

### Resource **HP support**

### Online chat with an HP technician.

- Find telephone numbers.
- Locate HP service center locations.

#### Product Notices, Warranty, and User Guide

- Safety and regulatory information
- The expressly provided HP Limited Warranty applicable to your tablet
- Product documentation

Serial number, product number, model number, and IMEI number Go to http://welcome.hp.com/support

On the Home screen, touch the HP User Guides app, touch , select your Region and Language, and then select HP Worldwide Limited Warranty and Technical Support. Product Notices or User Guide

On the back of the tablet

Location

### **Product description**

This product is a lightweight tablet and features a thin-panel display, processor, RAM, integrated battery pack, and an external AC adapter. This printed Quick Start quide identifies the hardware components of your tablet. The AC adapter has a rating of 100-240 V ac, 50/60 Hz, 0.3-1.0 A. You can access the latest user guide from the HP User **Guides** app.

### **Specification**

The tablet operates on DC power, which can be supplied by an AC or a DC power source. The AC power source must be rated 100-240 V, 50/60 Hz.

Note: The tablet can operate on DC power using an industrystandard micro-B USB cable. The HP adapter included with your tablet is recommended for charging the tablet.

Temperature Operating: Metric, 0°C to 40°C; U.S., 32°F to 104°F

Relative humidity (noncondensing) Operating: 10% to 90%

### Regulatory information

For regulatory identification purposes, your product is assigned a Regulatory Model Number (RMN), HSTNH-B407D. The RMN is located on the back of the tablet, and should not be confused with the marketing name (if any, etc.) or product numbers (HP P/N, etc.).

If required, regulatory markings for your country or region are located on the back of the unit. under the removable battery (if equipped), on the packaging, or elsewhere in this document. For more safety and regulatory information, refer to the Product Notices included with your tablet, accessible via the **HP User Guides** app.

### **Product notices**

Some notices may not apply to your product.

One or more integrated wireless devices are installed in this device. In some environments, the use of wireless devices may be restricted. Such restrictions may apply on-board airplanes, in hospitals, near explosives, in hazardous locations, and so on. If you are uncertain of the policy that applies to the use of this product, ask for authorization to use it before you turn it on.

### **Limited Warranty**

You can find the expressly provided HP Limited Warranty applicable to your product using the HP User **Guides** app. In some countries or regions, HP may provide a printed HP Limited Warranty in the box. For some countries or regions where the warranty is not provided in printed format, you may request a printed copy from http://www.hp.com/go/orderdocuments or write to:

Europe, Middle East, Africa: North America: Asia Pacific: Hewlett-Packard, MS POD. Hewlett-Packard, POD. Hewlett-Packard, POD, P.O. Box 200 11311 Chinden Blvd. Via G. Di Vittorio. 9 Alexandra Post Office. Boise, ID 83714, USA 20063 Cernusco s/Naviglio (MI), Italy Singapore 911507

When you request a printed copy of your warranty, please include your product number, name, and postal address.

**IMPORTANT:** Do NOT return your HP product to the addresses above. For U.S. support, go to http://www.hp.com/go/contactHP. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact\_us.html.



WARNING: To reduce the risk of electric shock or damage to the equipment, plug the AC adapter into an AC outlet that is easily accessible at all times.



WARNING: To reduce potential safety issues, only the AC adapter provided with the product, a replacement AC adapter provided by HP, or an AC adapter purchased as an accessory from HP should be used with the product.




WARNING: To reduce the possibility of heat-related injuries or of overheating the tablet, do not place the tablet directly on your lap. Do not allow a soft surface, such as pillows or rugs or clothing, to block airflow. Also, do not allow the AC adapter to contact the skin or a soft surface, such as pillows or rugs or clothing, during operation. The tablet and the AC adapter comply with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950-1).



WARNING: To reduce the risk of fire or burns, do not disassemble, crush, or puncture; do not short external contacts; do not dispose of in fire or water.



**WARNING:** To prevent possible hearing damage, do not listen at high volume levels for long periods.



# Quick Start



### Setting up your tablet

If a SIM card is not preinstalled in the tablet (select models only), install a SIM card (purchased separately) in the SIM slot.

After charging the battery, press **a**nd hold the power button **(b)** for about 2 seconds until the HP logo is displayed.





**IMPORTANT:** If the battery image is not displayed on the screen, press the power button (1) briefly to display the image, and then press and hold the power button (1) until the logo is displayed.

Tollow the on-screen instructions to select a language and a wireless network.



**Note:** Features may vary by model and country.

### **Using the Home screen**



**All apps**—Displays a list of all apps installed. To configure your preferences, touch (11), and then touch (12).



**Back**—Opens the previous screen.



**Home**—Opens or returns to the Home screen.



**Recent apps**—Opens a list of apps used recently.

**NOTE:** The icons on the Home screen and the appearance of the Home screen may vary.

### Search\*

Google **Search**—Allows you to type one or more keywords to search with the installed search app.



**Voice search**—Allows you to speak one or more keywords to search with the installed search app.

\*The search feature varies by model and country.

### Change your tablet's view

The Auto-rotate feature allows you to change your tablet's view. For landscape view, hold the tablet horizontally. For portrait view, hold the tablet vertically.

**NOTE:** Some apps do not rotate automatically.

To change the Auto-rotate setting, swipe down from the top right, and then touch to lock or unlock the screen rotation.

### Use gestures

The following gestures can be used with your tablet:







### **Use GPS**

To access the GPS feature, touch , touch Location, touch Mode, and then select the Location mode you want.

### Turn off the tablet

Press and hold the power button 0, touch **Power off**, and then touch 0K. If your tablet becomes unresponsive, press and hold the power button 0 for several seconds to turn off the tablet.

© Copyright 2014 Hewlett-Packard Development Company, L.P. Google and Google Play are trademarks of Google, Inc. SD Logo is a trademark of its proprietor. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical and editorial errors or omissions contained herein. First Edition: September 2014

## Display apps, widgets, and notifications

**Apps**—Touch (iii), and then touch the **Apps** tab to see a list of all apps.

**Widgets**—Touch (III), and then touch the **Widgets** tab to see a list of all widgets.

**Notifications**—Swipe down from the top left of the screen to see your notifications.

#### Use a micro SD card

Insert a micro SD card (purchased separately) in the micro SD slot.



### Lock and unlock

**Lock**—Press the power button.

### Back up your data

HP strongly encourages you to periodically back up your personal data and media on your tablet to another computer, a dedicated storage device, or to the cloud using one of several commercially available solutions.

For more information, you can access the user guide from the **HP User Guides** app.



You must be connected to a wireless network and signed into a Google account before you can access the Play Store to download apps.

- 1. On the Home screen, touch (iii), and then touch the **Play Store** app.
- To search for an app, touch the **Search** icon and then type a keyword, or touch a category.
- Scroll down to see the available apps, and then touch an app to select it.
- 4. Touch **Install**, and the app begins to download and install.

\*Select models only.



786903-001

Printed in China Imprimé en Chine Stampato in Cina Impreso en China Impresso na China 中国印刷 중국에서 인쇄